FS90 Simple V8 Basic Wiring Example. Use correct connections for each individual system.

STP = terminals = N/O Relay contact CC terminals = N/O Relay contact

All other connections are 24VDC referenced to 24vdc- terminal on FS90 Board

















